

```

1 import sys
2 sys.path.append('../modules')
3
4 from modules import rayTracing as rt
5 import numpy as np
6 import project_inputs as pi
7 import matplotlib.pyplot as plt
8 from mpl_toolkits.mplot3d import Axes3D
9 from Basilisk.utilities import RigidBodyKinematics as rbk
10 from tabulate import tabulate
11
12 exp = rt.Experiment()
13 rays = pi.edge_ray
14 rays = pi.basic_paraxial_rays
15 exp.set_ray_starts(rays.X)
16 exp.set_ray_start_dir(rays.d)
17
18 inst = pi.cass
19 inst-surfaces[-1] = pi.grating
20 inst-surfaces.append(pi.cylindrical_detector)
21 # inst-surfaces = inst-surfaces[-2:]
22 exp.add_instrument(inst)
23
24 wavelength_list = np.arange(1200., 2100., 100.)
25 grating = inst-surfaces[-2]
26 detector = inst-surfaces[-1]
27 data_list = []
28 colors = ['violet', 'indigo', 'blue', 'green', 'yellow', 'orange', '
red', 'pink', 'black',
29           'violet', 'indigo', 'blue', 'green', 'yellow', 'orange', '
red', 'pink', 'black',
30           'violet', 'indigo', 'blue', 'green', 'yellow', 'orange', '
red', 'pink', 'black']
31
32 grating.set_order(0)
33 for wavelength in wavelength_list:
34     grating.set_wavelength(wavelength)
35     exp.reset()
36     exp.trace_rays()
37     data_list.append(detector.extract_image(exp.ray_hist[-1]))
38 fig0 = rt.save_3d_plot(inst-surfaces, exp.ray_hist)
39
40 grating.set_order(1)
41 for wavelength in wavelength_list:
42     grating.set_wavelength(wavelength)
43     exp.reset()
44     exp.trace_rays()
45     data_list.append(detector.extract_image(exp.ray_hist[-1]))
46
47 angstrom_per_mm = 1E7 / 3600. / 1000.
48 x1600 = data_list[-5][0, :]
49 dx_1600 = (np.nanmax(x1600) - np.nanmin(x1600)) * 1000.
50 resolution_1600 = dx_1600 * angstrom_per_mm
51 resolving_power_1600 = 1600. / resolution_1600
52 print('resolving power at 1600 A: %f' % resolving_power_1600)
53 x1200 = data_list[-9][0, :]
54 dx_1200 = (np.nanmax(x1200) - np.nanmin(x1200)) * 1000.
55 resolution_1200 = dx_1200 * angstrom_per_mm
56 resolving_power_1200 = 1200. / resolution_1200
57 print('resolving power at 1200 A: %f' % resolving_power_1200)
58 x2000 = data_list[-1][0, :]

```

```

59 dx_2000 = (np.nanmax(x2000) - np.nanmin(x2000)) * 100.
60 resolution_2000 = dx_2000 * angstrom_per_mm
61 resolving_power_2000 = 2000. / resolution_2000
62 print('resolving power at 2000 A: %f' % resolving_power_2000)
63 headers = ['Wavelength', 'Resolving Power']
64 data = np.array([resolving_power_1200, resolving_power_1600,
65                  resolving_power_2000]).reshape([3, 1])
66 index = np.array([1200, 1600, 2000]).reshape([3, 1])
67 dat = np.hstack([index, data])
68 table = tabulate(dat, headers, tablefmt='latex')
69 with open('./resolvingTable.txt', 'w') as f:
70     f.write(table)
71     f.close()
72 fig1 = rt.save_3d_plot(inst.surfaces, exp.ray_hist)
73 plt.savefig('./figures/lab_view.png')
74
75 grating.set_order(2)
76 for wavelength in wavelength_list:
77     grating.set_wavelength(wavelength)
78     exp.reset()
79     exp.trace_rays()
80     data_list.append(detector.extract_image(exp.ray_hist[-1]))
81
82 scat_fig = plt.figure(figsize=(20, 5))
83 ax2 = scat_fig.add_subplot('111')
84 for order in range(3):
85     for col, wavelength in zip(colors, data_list):
86         # lab = 'order %s, wavelength %s' % (order, wavelength)
87         ax2.scatter(wavelength[0, :], wavelength[1, :]*100, s=1,
88                    color=col)
89 ax2.set_xlabel('RA [rad]')
90 ax2.set_ylabel('height (along cylinder axis) [cm]')
91 ax2.legend([str(int(w)) for w in wavelength_list], markerscale=6,
92            title='[A]')
93 ax2.text(0.575, 2., '0 order', bbox=dict(facecolor='black', alpha=0.05))
94 ax2.text(0., 2., 'first order', bbox=dict(facecolor='black', alpha=0.05))
95 ax2.text(-0.6, 2., 'second order', bbox=dict(facecolor='black', alpha=0.05))
96 plt.savefig('./figures/spectrum.png')
97 plt.show()
98
99 # fig = plt.figure()
100 # ax = fig.add_subplot('111', projection='3d')
101 # rt.plot_surfaces(ax, inst.surfaces)
102 # ax.set_xlabel('x')
103 # ax.set_ylabel('y')
104 # ax.set_zlabel('z')
105 # ax.set_aspect('equal')
106 # plt.show()
107
108
109

```